

Latest info Epson 7600-9600

Please Note: This Easy Flow System will only work with the UltraChrome Version of the Epson 7600/9600 Printers. The Photographic Dye Version is not currently supported.

The Epson 7600-9600 Easy Flow System is shipped with 2 types of Black cartridges Matte Black and Photo Black. Also included is a microchip resetter.

The 2 black option allows you to select the correct configuration for your setup

To setup your system with UltraChrome or similar pigment based ink the Photo Black cartridge option should be used, Though if you use Matte black Ink already, then use the Matte Black cartridge.

Artainium Ink or similar Dye-Sublimation Ink users must use and setup the printer with the Matte Black cartridge.

Operation Conditions:

While the system is in operation the Epson Status Monitor will show the ink levels go down as if it were working on standard ink cartridges.

Once the ink monitor shows low ink for one color or more (about 9%) and the ink lamp blinks on the printer, you can now reset the ink monitor back to full.

To reset the ink levels, raise up the cartridge change lever and wait about 15 seconds. Lower the Lever and the printer will reset one or more color cartridges to full (100%)

Microchip Resetter:

In some vary rare cases we have had customers say that intermittently a cartridge wont automatically reset. Some printers seem not to read the special reset instruction built into our cartridge chips. We supply the resetter unit, which allows you to manually reset any of the cartridges. This resetter can also be used to reset the Maintenance Tank.

Warning:

Be very careful when resetting the Maintenance Tank, as excessive ink overflow will eventually spill into the printer in which may be fatal to the printer

We recommend replacing this tank when it looks saturated with ink